



AIR ARMOR TECH

If you have any questions or comments,
please contact Air Armor Tech at the
following:

info@airarmortech.com
(817) 487-3837

For more product information, instructional
videos, and LIMITED LIFETIME
WARRANTY information, please visit
www.AirArmorTech.com.

**The ruggedness of a hard case with the
portability of a soft case; that's the
advantage of AIR.**

www.airarmortech.com



Made in America

A Veteran Owned Company

TACTICAL 12/EXTREME 16 INFLATABLE SCOPE COVER QUICK REFERENCE GUIDE



Thank you for choosing to purchase an Air Armor Tech™ product, the world's highest quality Inflatable Protection. The design and manufacturing of this Military-Grade gear, will assure you a lifetime of extreme performance in the field. No protective device on the planet protects better, is tougher, carries the weight of air, and collapses, like a patent pending Air Armor Tech™ product.

WARNING: ALWAYS ENSURE WEAPON IS UNLOADED AND IN A SAFE CONDITION PRIOR TO HANDLING. NEVER INSERT ANY STRAP ON OR NEAR TRIGGER, TRIGGER ASSEMBLY, OR FIRING MECHANISM.

1. Weapon Attachment:

- Lay deflated scope cover on top of optic(s) with American flag aligned with the stock end of optic.




Note: If you sling your weapon on your left shoulder, you may prefer to align the flag with the muzzle end of the optic.

- Secure straps and buckles under and around stock and handguard respectively; leave the straps slightly loose.



2. Inflation:

- Access oral inflation valve (red arrow).
- Unlock silver lock ring (blue arrow) by twisting clockwise.
- Depress rubber valve with teeth and blow.
- Re-lock silver ring by twisting counter-clockwise.



NOTE: If greater pressure is desired, either inflate mechanically via needle and BLACK rubber inflation valve (green arrow) — **DO NOT accidentally insert any object into the WHITE pressure relief valve** — or by holding air source against the oral inflation valve. Exercise caution when implementing alternate air sources for inflation. Excessive flow rates and pressure may exceed over-inflation valve capabilities and result in damage to the air bladder.



- Tighten securing straps and shock cord as necessary to ensure a snug fit around the optic.

3. Deflation:

- Unbuckle the straps and remove the scope cover from the weapon.
- Open deflation pocket and depress oral inflation valve while gently squeezing the bladder as necessary.
- Secure all straps, fold and stow.

NOTE: Scope cover can remain mounted to the optic/weapon system while deflated; however, it is NOT recommended to carry the weapon system by the carry handle as the weapon may slip loose.



Don't do the following with your Air Armor Tech™ Case:

- Insert inflation needle into WHITE pressure relief valve
- Use high-flow setting on air compressor for inflation
- Store sharp or pointy objects capable of puncturing the bladder