



AIR ARMOR TECH

If you have any questions or comments,
please contact Air Armor Tech at the
following:

info@airarmortech.com
(817) 487-3837

For more product information, instructional
videos, and LIMITED LIFETIME
WARRANTY information, please visit
www.AirArmorTech.com .

**The ruggedness of a hard case with the
portability of a soft case; that's the
advantage of AIR.**

www.airarmortech.com



Made in America

A Veteran Owned Company


AIR ARMOR
TECH

MID-LENGTH GUN CASE QUICK REFERENCE GUIDE



Thank you for choosing to purchase an Air Armor Tech™ product, the world's highest quality Inflatable Protection. The design and manufacturing of this Military-Grade gear, will assure you a lifetime of extreme performance in the field. No protective device on the planet protects better, is tougher, carries the weight of air, and collapses, like a patent pending Air Armor Tech™ product.


WARNING: ALWAYS ENSURE WEAPON IS UNLOADED AND IN A SAFE CONDITION PRIOR TO HANDLING. NEVER INSERT ANY STRAP ON OR NEAR TRIGGER, TRIGGER ASSEMBLY, OR FIRING MECHANISM.

1. Lay case flat and locate external deflation and inflation pockets. Confirm deflation cap is tightened and secure. **AVOID CROSS-THREADING.**



2. Inflation:

- Access oral inflation valve (red arrow)
- Unlock silver lock ring (blue arrow) by twisting clockwise
- Depress rubber valve with teeth and blow
- Re-lock silver ring by twisting counter-clockwise



NOTE: If greater pressure is desired, either inflate mechanically via needle and BLACK rubber inflation valve (green arrow) — DO NOT accidentally insert any object into the WHITE pressure relief valve — or by holding air source against the oral inflation valve. Exercise caution when implementing alternate air sources for inflation. Excessive flow rates and pressure may exceed over-inflation valve capabilities and result in damage to the air bladder.

3. Weapon Loading:

- Insert muzzle into pocket with the optic in desired position (depends on number of weapons carried).
- Secure weapon with Velcro straps.
- Close perimeter zipper.
- Secure and tighten lateral straps and carry handles.



4. Deflation:

- Open deflation pocket and partially or fully remove cap.
- Secure all straps and panels and roll from the opposite end of the deflation cap to allow air to escape.
- Secure by attaching 1" D-rings to MOLLE web on opposite side with provided bungee through one or two of the MOLLE loops. Expose handle for carrying ease.



Don't do the following with your Air Armor Tech™ Case:

- Insert inflation needle into WHITE pressure relief valve
- Use high-flow setting on air compressor for inflation
- Store sharp or pointy objects in the case which are capable of puncturing the bladder